


# Amana DG3801 09 - CLOTHES DRUM



**CLOTHES DRUM**

Amana [Residential Amana DG3801 Washer Parts](#) Parts Diagram 09 - CLOTHES DRUM  
 Click on the part number to view part

| Item | Original Part Number   | Replaced By              | Status        | Part Description |
|------|------------------------|--------------------------|---------------|------------------|
| 1    | <a href="#">51881</a>  |                          |               | Seal, Front      |
| 2    | <a href="#">50169</a>  |                          |               | Strap, Retainer  |
| 3    | 53137                  | <a href="#">53137ENG</a> |               | 50/50 Solder     |
| 4    | <a href="#">52310</a>  |                          |               | Spring           |
| 5    | <a href="#">50781</a>  |                          |               | Strap, Seal      |
| 6    | <a href="#">51883A</a> |                          |               | Assembly, Seal   |
| 7    | 51201                  |                          | Not Available | CLIP             |
| 8    | <a href="#">50168</a>  |                          |               | Spring           |