


Amana DG6161 11 - CONTROL PANEL & CONTROLS



CONTROL PANEL AND CONTROLS

Amana [Residential Amana DG6161 Washer Parts](#) Parts Diagram 11 - CONTROL PANEL & CONTROLS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	23402		Not Available	KNOB, CONTROL
2	23392		Not Available	CLIP FOR 26816 KNOB
3	24391		Not Available	KNURLED NUT
4	23407			Nut, Speed-8A Tinn C15
5	Y00000000		Not Available	SEE NOTE PANEL SUPPORT PLATE
6	91176			Lockwasher, 3/8 Intshkp
7	52623	58032		Switch
8	53516		Not Available	BUZZER
9	23962	W10116760		Screw
10	53563		Not Available	SWITCH, DOOR RELEASE
11	52947			Nut, Hex 15/32-32
12	53466		Not Available	TIMER
13	70212			Screw, 8-32 X 5/32 RD H
14	23406		Not Available	KNURLED NUT
15	54811		Not Available	CONTROL PANEL
16	23130		Not Available	SWITCH COLLAR

17	25285	Not Available	SETSCREW
18	24858	Not Available	ASSY,KNOB-TIMER
19	24857	Not Available	INDICATOR

