


# Amana DG6181 14 - DRUM LIGHT & COVER PLATE



[Amana Residential Amana DG6181 Washer Parts](#) Parts Diagram 14 - DRUM LIGHT & COVER PLATE  
Click on the part number to view part

| Item | Original Part Number | Replaced By              | Status        | Part Description                    |
|------|----------------------|--------------------------|---------------|-------------------------------------|
| 1    | Y54608               | <a href="#">31001575</a> |               | Bulb, Cylinder Light                |
| 2    | Y0054609             | <a href="#">M0270519</a> |               | Washer                              |
| 3    | 54610                |                          | Not Available | PLUG BUTTON                         |
| 4    | Y00000000            |                          | Not Available | SEE NOTE FRONT FRAME AND AIR SHROUD |