


# Amana DG6241 11 - DRUM LIGHT & COVER PLATE



[Amana Residential Amana DG6241 Washer Parts](#) Parts Diagram 11 - DRUM LIGHT & COVER PLATE  
Click on the part number to view part

| Item | Original Part Number | Replaced By | Status        | Part Description                    |
|------|----------------------|-------------|---------------|-------------------------------------|
| 3    | 54610                |             | Not Available | PLUG BUTTON                         |
| 4    | Y00000000            |             | Not Available | SEE NOTE FRONT FRAME AND AIR SHROUD |