


Amana DG9031 09 - CONTROL PANEL AND CONTROLS



Amana [Residential Amana DG9031 Washer Parts](#) Parts Diagram 09 - CONTROL PANEL AND CONTROLS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	24291			Assembly, Knob
2	23392		Not Available	CLIP FOR 26816 KNOB
3	53524		Not Available	CONTROL PANEL
4	24391		Not Available	KNURLED NUT
5	23407			Nut, Speed-8A Tinn C15
6	Y00000000		Not Available	SEE NOTE PANEL SUPPORT PLATE
7	91176			Lockwasher, 3/8 Intshkp
8	52623	58032		Switch
9	53516		Not Available	BUZZER
10	23962	W10116760		Screw
11	53563		Not Available	SWITCH,DOOR RELEASE
12	52947			Nut, Hex 15/32-32
13	53466		Not Available	TIMER
14	23401			Switch
15	23400		Not Available	FERRULE
16	70212			Screw, 8-32 X 5/32 RD H

17	23406	Not Available	KNURLED NUT
18	23399	Not Available	SWITCH COLLAR
19	23130	Not Available	SWITCH COLLAR
20	20310	Not Available	SCREW,8-32 X 1/4 HEX S
21	24290	Not Available	ASSY,KNOB-TIMER
22	24283		Indicator, Timer Knob

