


# Amana DLG330RCW (BOM: PDLG330RCW) 02 - CONTROL PANEL



Amana Residential Amana DLG330RCW (BOM: PDLG330RCW) Dryer Parts Parts Diagram 02 - CONTROL PANEL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
2	<a href="#">503674W</a>			Cover, Top
3	<a href="#">40084101</a>			Switch, Fab Sel-3 Position
4	40118801	<a href="#">40118801P</a>		Assembly-Signa
5	40112601	<a href="#">R0000409</a>		Timer
6	40012701W		Not Available	ENDCAP (RT-WHT)
7	<a href="#">40039610</a>			Panel, Support
8	<a href="#">40118901W</a>			Panel, Graphic
9	40013601W	<a href="#">37001064</a>		Knob- Time
10	<a href="#">38424W</a>			Switch, Rocker
11	40013402W	<a href="#">37001065</a>		Knob- Sele
12	<a href="#">40012702W</a>			Endcap