


# Amana DLW231RAW 05 - CONTROL PANEL



Amana [Residential Amana DLW231RAW Washer Parts](#) Parts Diagram 05 - CONTROL PANEL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">21001842</a>			Panel, Control
2	<a href="#">21001546</a>			Endcap, Panel
"	25-3092	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
3	<a href="#">21001547</a>			Endcap, Panel
"	25-3092	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
4	25-3092	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
"	<a href="#">21001139</a>			Switch, Water Temp. 3 Position
5	<a href="#">21001882</a>			Switch, Pressure
"	25-3092	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
"	<a href="#">21001554</a>			Switch, Water Level
6	21001843	<a href="#">21001520</a>		Skirt, Timer Knob
7	<a href="#">21001844</a>			Knob, Timer
8	<a href="#">21001517</a>			Shield, Control

9	<a href="#">21001553</a>		Frame
10	25-3092	<a href="#">90767</a>	Screw, 8A X 3/8 HeX Washer Head Tapping
"	<a href="#">21001527</a>		Shield, Rear
11	<a href="#">21001561</a>		Timer
"	25-3092	<a href="#">90767</a>	Screw, 8A X 3/8 HeX Washer Head Tapping
12	21001845	<a href="#">21001544</a>	Knob, Selector
13	<a href="#">21001813</a>		Switch, Rocker
14	<a href="#">21001948</a>		Harness, Wiring
"	21001846	Not Available	MANUAL, USE & CARE
"	<a href="#">21001848</a>		Harness, Wire
"	22003218	Not Available	LAUNDERING TIPS (TRILINGUAL)

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>