


Amana DLW330RAW 11 - TOP, LID AND LID SWITCH



Amana Residential Amana DLW330RAW Washer Parts Parts Diagram 11 - TOP, LID AND LID SWITCH
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	40111301WP	27001093		Lid
2	40121402			Panel, Back
3	501086	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
4	40038001			Bumper
5	40039201	W10119828		Screw, Lid Hinge Mounting
6	40008201			Bushing, Hinge
7	40094002			Hinge, Lid Left Stop
8	40094101			Hinge, Lid Right Pass
9	40093901			Dispenser, Bleach
10	40063901			Clip, Hold Down
11	40000202WP	27001182		Top
12	40102101			Cap, Hinge
13	503661	27001200		Screw
14	56080	22001650		Fastener, Spring
15	501086	90767		Screw, 8A X 3/8 HeX Washer Head Tapping

16	40035001	27001095	Switch, Lid
17	40040701		Screw, Tapping No.6b-20
18	40009801		Holder, Lid Switch
19	40009701		Arm, Lid Switch

