

Amana DLW330RAW (BOM: PDLW330RAW) 04 - CABINET TOP, DOOR, AND DOOR SWITCH




Image 1




Image 2

Amana Residential Amana DLW330RAW (BOM: PDLW330RAW) Washer Parts Parts Diagram 04 - CABINET TOP, DOOR, AND DOOR SWITCH
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	40111301W	27001093		Lid
2	40051401		Not Available	PANEL,HOME HOOD BACK
4	40038001			Bumper
5	40039201	W10119828		Screw, Lid Hinge Mounting
6	40008201			Bushing, Hinge
7	40094002			Hinge, Lid Left Stop
8	40094101			Hinge, Lid Right Pass
10	40093901			Dispenser, Bleach
11	40063901			Clip, Hold Down
12	40000202W	27001182		Top
13	40102101			Cap, Hinge
15	56080	22001650		Fastener, Spring
17	40076401WP	37001284		Cabinet As Pack
18	40035001	27001095		Switch, Lid
19	40040701			Screw, Tapping No.6b-20

