


# Amana FA2130 10 - CONTROL PANEL & CONTROLS



## CONTROL PANEL AND CONTROLS

Amana [Residential Amana FA2130 Washer Parts](#) Parts Diagram 10 - CONTROL PANEL & CONTROLS  
 Click on the part number to view part

| Item | Original Part Number  | Replaced By               | Status        | Part Description               |
|------|-----------------------|---------------------------|---------------|--------------------------------|
| 1    | <a href="#">27371</a> |                           |               | Screw                          |
| 2    | 21300                 |                           | Not Available | SWITCH,TEMPERATURE             |
| 3    | <a href="#">91176</a> |                           |               | Lockwasher, 3/8 Intshkp        |
| 5    | Y00000000             |                           | Not Available | SEE NOTE PRESSURE SWITCH       |
| 6    | 23962                 | <a href="#">W10116760</a> |               | Screw                          |
| 7    | 25232                 |                           | Not Available | SCREW,8AB-18X7/8 OVAL          |
| 8    | 25123                 |                           | Not Available | CONTROL HOOD END, RIGHT        |
| 9    | <a href="#">26918</a> |                           |               | Timer                          |
| 10   | Y00000000             |                           | Not Available | SEE NOTE PANEL BRACKET SUPPORT |
| 11   | 24859                 |                           | Not Available | SLEEVE,SUPPORT ANGLE           |
| 12   | 26326                 |                           | Not Available | TIMER KNOB INDICATOR           |
| 13   | <a href="#">70212</a> |                           |               | Screw, 8-32 X 5/32 RD H        |
| 14   | <a href="#">26319</a> |                           |               | Spring                         |
| 15   | <a href="#">26318</a> |                           |               | Screw, 8-32 X 1/4 Set S        |

|    |                       |                            |                        |
|----|-----------------------|----------------------------|------------------------|
| 16 | 27382                 | Not Available              | TIMER KNOB             |
| 17 | 23392                 | Not Available              | CLIP FOR 26816 KNOB    |
| 18 | <a href="#">24205</a> |                            | Nut, Knurled 3/8-24    |
| 19 | 27376                 | Not Available              | No Longer Available    |
| 20 | 25124                 | Not Available              | CONTROL HOOD END, LEFT |
| 21 | 25126                 | <a href="#">5303284616</a> | Clip                   |

