


Amana FA3040 06 - BOOT, CHASSIS & DRAIN TUB



BOOT, CHASSIS AND DRAIN TUB

Amana [Residential Amana FA3040 Washer Parts](#) Parts Diagram 06 - BOOT, CHASSIS & DRAIN TUB
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	20107			Upper Clamp
2	20108	F200201		Clamp Hose #56
3	20118		Not Available	GROMMET,1982 INV
4	20305	20-305		Sizzle Do Not Ship Ups
5	21393	21-393		Piezo Sounder
6	21651			Grommet
7	23258			Pad, Bumper
8	26034M		Not Available	ASSY,SPLASH TUB
9	10108			Seal
10	21905			Plate, Snubber
11	20275	27001225		Nut, Jam Mid Lock 1/4-20
12	03189			LoCkwasher, 1/4 Std-C P
13	02422			Screw, 1/4-20 X 1/2 HeX
14	20162		Not Available	SPACER
15	20195		Not Available	GROMMET
16	26012	2-6012		Blower Wheel

17	22837		Not Available	STRAP,WIRE
18	21749	40016001		Foot, Rubber
19	20409	22003428		Leg, Adjustable
20	Y21899	40038101		Nut, Leg
21	26028			Assembly, Chassis xReplace
22	25112			Hose
23	20115			Grommet
24	23257		Not Available	PAD,BUMPER
25	22818		Not Available	HOSE
26	21233		Not Available	GASKET
27	20112			Grommet
28	20111			Washer
29	20259		Not Available	SCREW
30	20129		Not Available	BOOT

