

# Amana FA3530 11 - DOOR SAFETY SWITCH



**DOOR SAFETY SWITCH**

Amana [Residential Amana FA3530 Washer Parts](#) Parts Diagram 11 - DOOR SAFETY SWITCH  
 Click on the part number to view part

| Item | Original Part Number  | Replaced By              | Status        | Part Description         |
|------|-----------------------|--------------------------|---------------|--------------------------|
| 1    | <a href="#">23591</a> |                          |               | Diaphragm                |
| 2    | Y02370                |                          | Not Available | SCREW,10-24X15/16 HEX    |
| 3    | <a href="#">22001</a> |                          |               | Nut, 10-24 Nylon Hex BR  |
| 4    | <a href="#">51783</a> |                          |               | Screw, 6b-20 X 7/8 HeX   |
| 5    | 23540                 |                          | Not Available | SWITCH                   |
| 6    | 23592                 |                          | Not Available | ARM                      |
| 7    | 26766                 |                          | Not Available | SPRING                   |
| 8    | 23951                 | <a href="#">M0282009</a> |               | Nut                      |
| 9    | 22783                 |                          | Not Available | BRACKET                  |
| 10   | 21735                 |                          | Not Available | LOCKWASHER,No.10 INTSHKP |
| 11   | 02928                 |                          | Not Available | WASHER                   |
| 12   | 20492                 | <a href="#">M0270504</a> |               | Washer                   |
| 13   | <a href="#">21081</a> |                          |               | Screw, 10-24 X 1/2 RD H  |
| 14   | Y00000000             |                          | Not Available | SEE NOTE DRAIN TUB       |