


# Amana FA4111 10 - CONTROL PANEL & CONTROLS



## CONTROL PANEL AND CONTROLS

Amana [Residential Amana FA4111 Washer Parts](#) Parts Diagram 10 - CONTROL PANEL & CONTROLS  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	24846		Not Available	CONTROL PANEL
2	24392		Not Available	SWITCH TEMP
3	<a href="#">91176</a>			Lockwasher, 3/8 Intshkp
4	<a href="#">21302</a>			Switch, Motor-2SP
5	23962	<a href="#">W10116760</a>		Screw
6	Y00000000		Not Available	SEE NOTE PRESSURE SWITCH
7	25232		Not Available	SCREW,8AB-18X7/8 OVAL
8	25123		Not Available	CONTROL HOOD END, RIGHT
9	26410		Not Available	TIMER
10	Y00000000		Not Available	SEE NOTE PANEL SUPPORT BRACKET
11	24859		Not Available	SLEEVE,SUPPORT ANGLE
12	26326		Not Available	TIMER KNOB INDICATOR
13	<a href="#">70212</a>			Screw, 8-32 X 5/32 RD H
14	<a href="#">26319</a>			Spring

15	<a href="#">26798</a>		Knob, Timer xReplace
16	<a href="#">26318</a>		Screw, 8-32 X 1/4 Set S
17	23392	Not Available	CLIP FOR 26816 KNOB
18	26818	Not Available	CONTROL KNOB ASSEMBLY
19	22244	Not Available	CLIP,C xREPLACE
20	22245	Not Available	xREPLACE
21	<a href="#">24205</a>		Nut, Knurled 3/8-24
22	25124	Not Available	CONTROL HOOD END, LEFT
23	25126	<a href="#">5303284616</a>	Clip

