


# Amana FA4111 11 - DOOR SAFETY SWITCH



**DOOR SAFETY SWITCH**

Amana [Residential Amana FA4111 Washer Parts](#) Parts Diagram 11 - DOOR SAFETY SWITCH  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">23591</a>			Diaphragm
2	Y02370		Not Available	SCREW,10-24X15/16 HEX
3	<a href="#">22001</a>			Nut, 10-24 Nylon Hex BR
4	<a href="#">51783</a>			Screw, 6b-20 X 7/8 HeX
5	23540		Not Available	SWITCH
6	23592		Not Available	ARM
7	26766		Not Available	SPRING
8	23951	<a href="#">M0282009</a>		Nut
9	22783		Not Available	BRACKET
10	21735		Not Available	LOCKWASHER,No.10 INTSHKP
11	02928		Not Available	WASHER
12	20492	<a href="#">M0270504</a>		Washer
13	<a href="#">21081</a>			Screw, 10-24 X 1/2 RD H
14	Y00000000		Not Available	SEE NOTE DRAIN TUB