


Amana FA4320 10 - CONTROL PANEL & CONTROLS



CONTROL PANEL AND CONTROLS

Amana [Residential Amana FA4320 Washer Parts](#) Parts Diagram 10 - CONTROL PANEL & CONTROLS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	24392		Not Available	SWITCH TEMP
2	91176			Lockwasher, 3/8 Intshkp
4	23962	W10116760		Screw
5	Y00000000		Not Available	SEE NOTE PRESSURE SWITCH
6	25232		Not Available	SCREW,8AB-18X7/8 OVAL
7	25123		Not Available	CONTROL HOOD END, RIGHT
8	26324		Not Available	TIMER
9	Y00000000		Not Available	SEE NOTE PANEL SUPPORT BRACKET
10	24859		Not Available	SLEEVE,SUPPORT ANGLE
11	26326		Not Available	TIMER KNOB INDICATOR
12	70212			Screw, 8-32 X 5/32 RD H
13	26319			Spring
14	26318			Screw, 8-32 X 1/4 Set S
15	27382		Not Available	TIMER KNOB

16	23392	Not Available	CLIP FOR 26816 KNOB
18	27379	Not Available	ASSY,KNOB-SWITCH
19	24205		Nut, Knurled 3/8-24
20	25124	Not Available	CONTROL HOOD END, LEFT
21	25126	5303284616	Clip
22	27375	Not Available	CONTROL PANEL

