


Amana FA6022 10 - CONTROL PANEL & CONTROLS



CONTROL PANEL AND CONTROLS

Amana [Residential Amana FA6022 Washer Parts](#) Parts Diagram 10 - CONTROL PANEL & CONTROLS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y24206		Not Available	NUT,KNURLED
2	25820		Not Available	LOCKWASHER,1/2 INT SHK
3	21286		Not Available	SUDS-WATER SAVER SWITCH
4	24392		Not Available	SWITCH TEMP
5	91176			Lockwasher, 3/8 Intshkp
6	24431		Not Available	SPEED SWITCH
7	25232		Not Available	SCREW,8AB-18X7/8 OVAL
8	25123		Not Available	CONTROL HOOD END, RIGHT
9	26970		Not Available	TIMER
10	70212			Screw, 8-32 X 5/32 RD H
11	26326		Not Available	TIMER KNOB INDICATOR
12	Y00000000		Not Available	SEE NOTE PANEL SUPPORT BRACKET
13	24859		Not Available	SLEEVE,SUPPORT ANGLE
14	26319			Spring

15	26798		Knob, Timer xReplace
16	26318		Screw, 8-32 X 1/4 Set S
17	26980	Not Available	CONTROL PANEL
18	24205		Nut, Knurled 3/8-24
19	23392	Not Available	CLIP FOR 26816 KNOB
20	26816		Assembly, Knob-Switch
21	25124	Not Available	CONTROL HOOD END, LEFT
22	25126	5303284616	Clip
23	23379	Not Available	SWITCH PLATE

