


Amana FA6311 10 - CONTROL PANEL & CONTROLS



CONTROL PANEL AND CONTROLS

Amana [Residential Amana FA6311 Washer Parts](#) Parts Diagram 10 - CONTROL PANEL & CONTROLS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	27368			Sub Ra43301
2	21300		Not Available	SWITCH,TEMPERATURE
3	91176			Lockwasher, 3/8 Intshkp
4	21302			Switch, Motor-2SP
5	23962	W10116760		Screw
6	Y00000000		Not Available	SEE NOTE PRESSURE SWITCH
7	25232		Not Available	SCREW,8AB-18X7/8 OVAL
8	25123		Not Available	CONTROL HOOD END, RIGHT
9	70212			Screw, 8-32 X 5/32 RD H
10	26326		Not Available	TIMER KNOB INDICATOR
11	26319			Spring
12	24859		Not Available	SLEEVE,SUPPORT ANGLE
13	26918			Timer
14	Y00000000		Not Available	SEE NOTE PANEL SUPPORT BRACKET

15	27382	Not Available	TIMER KNOB
16	26318		Screw, 8-32 X 1/4 Set S
17	23392	Not Available	CLIP FOR 26816 KNOB
19	27379	Not Available	ASSY,KNOB-SWITCH
20	24205		Nut, Knurled 3/8-24
21	25124	Not Available	CONTROL HOOD END, LEFT
22	25126	5303284616	Clip

