


Amana FA6611 10 - CONTROL PANEL & CONTROLS



CONTROL PANEL AND CONTROLS

Amana [Residential Amana FA6611 Washer Parts](#) Parts Diagram 10 - CONTROL PANEL & CONTROLS
 Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|-----------------------|---------------------------|---------------|--------------------------------|
| 1 | 24392 | | Not Available | SWITCH TEMP |
| 2 | 91176 | | | Lockwasher, 3/8 Intshkp |
| 3 | 24431 | | Not Available | SPEED SWITCH |
| 4 | 23962 | W10116760 | | Screw |
| 5 | Y00000000 | | Not Available | SEE NOTE PRESSURE SWITCH |
| 6 | 25232 | | Not Available | SCREW,8AB-18X7/8 OVAL |
| 7 | 25123 | | Not Available | CONTROL HOOD END, RIGHT |
| 8 | 26324 | | Not Available | TIMER |
| 9 | Y00000000 | | Not Available | SEE NOTE PANEL SUPPORT BRACKET |
| 10 | 24859 | | Not Available | SLEEVE,SUPPORT ANGLE |
| 11 | 26326 | | Not Available | TIMER KNOB INDICATOR |
| 12 | 70212 | | | Screw, 8-32 X 5/32 RD H |
| 13 | 26319 | | | Spring |
| 14 | 26318 | | | Screw, 8-32 X 1/4 Set S |

| | | | |
|----|-----------------------|----------------------------|------------------------|
| 15 | 27382 | Not Available | TIMER KNOB |
| 16 | 23392 | Not Available | CLIP FOR 26816 KNOB |
| 17 | 27379 | Not Available | ASSY,KNOB-SWITCH |
| 18 | 27379 | Not Available | ASSY,KNOB-SWITCH |
| 19 | 24205 | | Nut, Knurled 3/8-24 |
| 20 | 25124 | Not Available | CONTROL HOOD END, LEFT |
| 21 | 25126 | 5303284616 | Clip |
| 22 | 27367 | Not Available | No Longer Available |

