


Amana FA9101 10 - CONTROL PANEL AND CONTROLS



Amana Residential Amana FA9101 Washer Parts Parts Diagram 10 - CONTROL PANEL AND CONTROLS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	24291			Assembly, Knob
2	23392		Not Available	CLIP FOR 26816 KNOB
3	24503		Not Available	CONTROL PANEL
4	24391		Not Available	KNURLED NUT
5	23222	3177991		Screw
6	21975		Not Available	BALLAST
7	24522			Nut, Speed-8ab-18 C1995
8	Y00000000		Not Available	SEE NOTE PANEL SUPPORT PLATE
9	24392		Not Available	SWITCH TEMP
10	91176			Lockwasher, 3/8 Intshkp
11	24431		Not Available	SPEED SWITCH
12	Y00000000		Not Available	SEE NOTE PRESSURE SWITCH
13	23962	W10116760		Screw
14	25820		Not Available	LOCKWASHER, 1/2 INT SHK
15	25054		Not Available	TIMER, SOAK

16	25042	Not Available	SPEED NUT
17	26411		Timer
18	23401		Switch
19	25043	Not Available	WASHER
20	70212		Screw, 8-32 X 5/32 RD H
21	23400	Not Available	FERRULE
22	23406	Not Available	KNURLED NUT
23	23399	Not Available	SWITCH COLLAR
24	25045	Not Available	INDICATOR LIGHT
25	26326	Not Available	TIMER KNOB INDICATOR
26	26319		Spring
27	26321	Not Available	TIMER KNOB
28	26318		Screw, 8-32 X 1/4 Set S
29	Y22579	Not Available	SETSCREW
30	25049	Not Available	KNOB,CONTROL

