


# Amana FA9103 14 - CONTROL PANEL AND CONTROLS



Amana Residential Amana FA9103 Washer Parts Parts Diagram 14 - CONTROL PANEL AND CONTROLS  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">24291</a>			Assembly, Knob
2	23392		Not Available	CLIP FOR 26816 KNOB
3	24504		Not Available	CONTROL PANEL
4	24391		Not Available	KNURLED NUT
5	23222	<a href="#">3177991</a>		Screw
6	21975		Not Available	BALLAST
7	<a href="#">24522</a>			Nut, Speed-8ab-18 C1995
8	Y00000000		Not Available	SEE NOTE PANEL SUPPORT PLATE -- (SEE PAGE 3, KEY 12)
9	<a href="#">91176</a>			Lockwasher, 3/8 Intshkp
10	24392		Not Available	SWITCH TEMP
11	24431		Not Available	SPEED SWITCH
12	26051		Not Available	SWITCH,PRESSURE
13	23962	<a href="#">W10116760</a>		Screw
14	24580		Not Available	SUDS-WATER SAVER SWITCH

15	24290	Not Available	ASSY,KNOB-TIMER
16	20310	Not Available	SCREW,8-32 X 1/4 HEX S
17	<a href="#">24283</a>		Indicator, Timer Knob
18	23399	Not Available	SWITCH COLLAR
19	23406	Not Available	KNURLED NUT
20	23400	Not Available	FERRULE
21	<a href="#">70212</a>		Screw, 8-32 X 5/32 RD H
22	25043	Not Available	WASHER
23	25042	Not Available	SPEED NUT
24	<a href="#">23401</a>		Switch
25	25045	Not Available	INDICATOR LIGHT
26	<a href="#">24815</a>		Timer

**Howes**  
*the laundry company*<sup>®</sup>

**Howes**  
*the laundry company*<sup>®</sup>

**Howes**  
*the laundry company*<sup>®</sup>