


Amana FA9151 10 - CONTROL PANEL AND CONTROLS



Amana Residential Amana FA9151 Washer Parts Parts Diagram 10 - CONTROL PANEL AND CONTROLS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	26816			Assembly, Knob-Switch
2	23392		Not Available	CLIP FOR 26816 KNOB
3	26785			Control Panel
4	24391		Not Available	KNURLED NUT
5	23222	3177991		Screw
6	21975		Not Available	BALLAST
7	24522			Nut, Speed-8ab-18 C1995
8	24392		Not Available	SWITCH TEMP
9	91176			Lockwasher, 3/8 Intshkp
10	24431		Not Available	SPEED SWITCH
11	Y00000000		Not Available	SEE NOTE PRESSURE SWITCH
12	23962	W10116760		Screw
13	Y00000000		Not Available	SEE NOTE PANEL SUPPORT PLATE
14	26411			Timer
15	23401			Switch

16	70212		Screw, 8-32 X 5/32 RD H
17	23400	Not Available	FERRULE
18	23399	Not Available	SWITCH COLLAR
19	26326	Not Available	TIMER KNOB INDICATOR
20	26319		Spring
21	26798		Knob, Timer xReplace
22	26318		Screw, 8-32 X 1/4 Set S

