


Amana FA9211 10 - CONTROL PANEL AND CONTROLS



Amana Residential Amana FA9211 Washer Parts Parts Diagram 10 - CONTROL PANEL AND CONTROLS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	27379		Not Available	ASSY,KNOB-SWITCH
2	23392		Not Available	CLIP FOR 26816 KNOB
3	24391		Not Available	KNURLED NUT
4	23222	3177991		Screw
5	21975		Not Available	BALLAST
6	24522			Nut, Speed-8ab-18 C1995
7	24392		Not Available	SWITCH TEMP
8	91176			Lockwasher, 3/8 Intshkp
9	24431		Not Available	SPEED SWITCH
10	23962	W10116760		Screw
11	Y00000000		Not Available	SEE NOTE PRESSURE SWITCH
12	Y00000000		Not Available	SEE NOTE PANEL SUPPORT PLATE
13	26411			Timer
14	23401			Switch
15	70212			Screw, 8-32 X 5/32 RD H

16	23400	Not Available	FERRULE
17	23399	Not Available	SWITCH COLLAR
18	26326	Not Available	TIMER KNOB INDICATOR
19	27382	Not Available	TIMER KNOB
20	26318		Screw, 8-32 X 1/4 Set S
21	26319		Spring
22	27350	Not Available	CONTROL PANEL

