


# Amana FG3070 02 - CLOTHES DRUM



Amana [Residential Amana FG3070 Washer Parts](#) Parts Diagram 02 - CLOTHES DRUM  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">53135</a>			Assembly, Drum
2	<a href="#">52310</a>			Spring
3	<a href="#">50781</a>			Strap, Seal
4	<a href="#">51883A</a>			Assembly, Seal
5	51201		Not Available	CLIP
6	<a href="#">50168</a>			Spring
7	<a href="#">51881</a>			Seal, Front
8	<a href="#">50169</a>			Strap, Retainer