


# Amana FG3070 03 - CONTROL PANEL, CONTROL HOOD AND CONTROLS



Amana Residential Amana FG3070 Washer Parts Parts Diagram 03 - CONTROL PANEL, CONTROL HOOD AND CONTROLS

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">24291</a>			Assembly, Knob
2	25232		Not Available	SCREW,8AB-18X7/8 OVAL
3	25072		Not Available	END CAP, LEFT
4	Y54971		Not Available	CONTROL PANEL
5	<a href="#">54038</a>			NUt, Speed U-Type
6	52530W		Not Available	CONTROL HOOD, WHITE
"	52530H		Not Available	CONTROL HOOD, HARVEST GOLD
"	52530A		Not Available	CONTROL HOOD, AVOCADO
7	52539GR		Not Available	CONTROL HOOD REAR COVER, GRAY
8	23222	<a href="#">3177991</a>		Screw
9	25724		Not Available	HEX HEAD SCREW
10	23028		Not Available	GASKET,CONTROL BOX END
11	Y00000000		Not Available	SEE NOTE CABINET TOP

12	23962	<a href="#">W10116760</a>	Screw
13	<a href="#">91176</a>		Lockwasher, 3/8 Intshkp
14	53380	Not Available	TEMPERATURE SELECTOR SWITCH
15	25966	Not Available	SPACER,TIMER
16	25073	Not Available	END CAP, RIGHT
17	52594	Not Available	TIMER
18	53768	<a href="#">55882P</a>	Assembly- Switch
19	<a href="#">52947</a>		Nut, Hex 15/32-32
20	52864	<a href="#">500226</a>	Screw, 8b-16 x 5/8 Tap
21	Y0053880	Not Available	ACTUATOR, WATER
22	Y0054441	Not Available	NAMEPLATE, HANDLE
23	<a href="#">24205</a>		Nut, Knurled 3/8-24
24	23392	Not Available	CLIP FOR 26816 KNOB
25	<a href="#">24283</a>		Indicator, Timer Knob
26	20310	Not Available	SCREW,8-32 X 1/4 HEX S
27	24290	Not Available	ASSY,KNOB-TIMER

