


Amana FG3070 04 - DOOR RELEASE



Amana [Residential Amana FG3070 Washer Parts](#) Parts Diagram 04 - DOOR RELEASE
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	51065		Not Available	DOOR RELEASE SPRING
2	51786		Not Available	PLUG
3	51841		Not Available	DOOR RELEASE PIN ASSEMBLY
4	02578			Pin, Cotter
5	51041		Not Available	DOOR RELEASE LEVER
6	51161		Not Available	PIN,ROLL 1/8 X 3/4
7	51121			Door Release Spacer
8	51837		Not Available	DOOR RELEASE ROD
9	02578			Pin, Cotter
10	51045		Not Available	PEDAL HINGE PIN
11	51046		Not Available	NYLON WASHER
12	51271		Not Available	NUT
13	51802			Pedal, Foot
14	51844		Not Available	DOOR RELEASE ASSEMBLY
15	51246		Not Available	SCREW
16	51052		Not Available	DOOR RELEASE BRACKET

