


Amana FG3140 03 - CONTROL PANEL, CONTROL HOOD AND CONTROLS



Amana Residential Amana FG3140 Washer Parts Parts Diagram 03 - CONTROL PANEL, CONTROL HOOD AND CONTROLS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	25232		Not Available	SCREW,8AB-18X7/8 OVAL
2	25072		Not Available	END CAP, LEFT
3	0055876		Not Available	PULLEY IDLER
4	91176			Lockwasher, 3/8 Intshkp
5	53380		Not Available	TEMPERATURE SELECTOR SWITCH
6	54038			NUt, Speed U-Type
7	55909W		Not Available	CONTROL HOOD
8	52539GR		Not Available	CONTROL HOOD REAR COVER, GRAY
9	55985	W10116760		Screw
10	23028		Not Available	GASKET,CONTROL BOX END
11	Y00000000		Not Available	SEE NOTE CABINET TOP
12	26952		Not Available	SPACER
13	52610		Not Available	TIMER

14	25073	Not Available	END CAP, RIGHT
15	53768	55882P	Assembly- Switch
16	52947		Nut, Hex 15/32-32
17	25820	Not Available	LOCKWASHER,1/2 INT SHK
18	52864	500226	Screw, 8b-16 x 5/8 Tap
19	Y0053880	Not Available	ACTUATOR, WATER
20	Y0054441	Not Available	NAMEPLATE, HANDLE
21	24205		Nut, Knurled 3/8-24
22	23392	Not Available	CLIP FOR 26816 KNOB
23	24291		Assembly, Knob
24	24857	Not Available	INDICATOR
25	25285	Not Available	SETSCREW
26	24858	Not Available	ASSY,KNOB-TIMER

the laundry company®

the laundry company®

the laundry company®