


Amana FG3140 09 - HEATER BOX



Amana [Residential Amana FG3140 Washer Parts](#) Parts Diagram 09 - HEATER BOX
 Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|----------------------|--------------------------|---------------|-------------------------------------|
| 1 | 25723 | 27001200 | | Screw |
| 2 | 55428 | | Not Available | SENSOR |
| 3 | 23222 | 3177991 | | Screw |
| 4 | Y55742 | | Not Available | THERMOSTAT |
| 5 | 0055427 | | Not Available | USE B5716202 |
| 6 | 55426 | | Not Available | ASSY,HEATER BOX LINER |
| 7 | Y0051866 | | Not Available | SUB 58627CG, OVEN BOTTOM |
| 8 | 52552 | | Not Available | BUMPER, OVEN DOOR |
| 9 | Y00000000 | | Not Available | SEE NOTE REAR FRAME |
| 10 | Y52584 | | Not Available | BURNER SHIELD |
| 11 | Y00000000 | | Not Available | SEE NOTE FRONT FRAME AND AIR SHROUD |