


# Amana FG4181 09 - HEATER BOX



Amana [Residential Amana FG4181 Dryer Parts](#) Parts Diagram 09 - HEATER BOX  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	25723	<a href="#">27001200</a>		Screw
2	55428		Not Available	SENSOR
3	23222	<a href="#">3177991</a>		Screw
4	Y55742		Not Available	THERMOSTAT
5	0055427		Not Available	USE B5716202
6	55426		Not Available	ASSY,HEATER BOX LINER
7	Y0051866		Not Available	SUB 58627CG, OVEN BOTTOM
8	52552		Not Available	BUMPER, OVEN DOOR
9	Y00000000		Not Available	SEE NOTE REAR FRAME
10	Y52584		Not Available	BURNER SHIELD
11	Y00000000		Not Available	SEE NOTE FRONT FRAME AND AIR SHROUD