


# Amana FG6041 03 - CONTROL PANEL, CONTROL HOOD AND CONTROLS



Amana Residential Amana FG6041 Dryer Parts Parts Diagram 03 - CONTROL PANEL, CONTROL HOOD AND CONTROLS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	23392		Not Available	CLIP FOR 26816 KNOB
2	<a href="#">26816</a>			Assembly, Knob-Switch
3	<a href="#">24205</a>			Nut, Knurled 3/8-24
4	25124		Not Available	CONTROL HOOD END, LEFT
5	25126	<a href="#">5303284616</a>		Clip
6	55883		Not Available	PANEL,CONTROL
7	<a href="#">91176</a>			Lockwasher, 3/8 Intshkp
8	52623	<a href="#">58032</a>		Switch
9	53516		Not Available	BUZZER
10	23962	<a href="#">W10116760</a>		Screw
11	25820		Not Available	LOCKWASHER,1/2 INT SHK
12	<a href="#">52947</a>			Nut, Hex 15/32-32
13	55882	<a href="#">55882P</a>		Assembly- Switch
14	25232		Not Available	SCREW,8AB-18X7/8 OVAL
15	53466		Not Available	TIMER

16	<a href="#">24522</a>		Nut, Speed-8ab-18 C1995
17	23028	Not Available	GASKET,CONTROL BOX END
18	55985	<a href="#">W10116760</a>	Screw
19	Y00000000	Not Available	SEE NOTE CABINET TOP
20	23425	Not Available	WASHER,7/32IDX7/16ODX.
21	55906A	Not Available	CONTROL HOOD, AVOCADO
"	55906H	Not Available	CONTROL HOOD, HARVEST GOLD
"	55906W	Not Available	CONTROL HOOD, WHITE
22	52912	Not Available	PANEL SUPPORT BRACKET
23	24859	Not Available	SLEEVE,SUPPORT ANGLE
24	25123	Not Available	CONTROL HOOD END, RIGHT
25	<a href="#">70212</a>		Screw, 8-32 X 5/32 RD H
26	<a href="#">52947</a>		Nut, Hex 15/32-32
27	55900	Not Available	TIMER KNOB ASSEMBLY
28	<a href="#">24283</a>		Indicator, Timer Knob
29	20310	Not Available	SCREW,8-32 X 1/4 HEX S

