


Amana HA4521 21 - SWITCH & BRACKET ASSY



SWITCH AND BRACKET ASSEMBLY

Amana [Residential Amana HA4521 Washer Parts](#) Parts Diagram 21 - SWITCH & BRACKET ASSY
 Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|------------------------|-------------|---------------|--------------------------|
| 1 | 29042 | | Not Available | SHIELD,LID SWITCH |
| 2 | Q6516 | | Not Available | SCREW,6-32 X 1 ROUND H |
| 3 | 27249 | | Not Available | SWITCH |
| 4 | 27602 | | | Lever, Out-Of-Bal Switch |
| 5 | 29043 | | | Nut, Push |
| 6 | 27603 | | | Spring, Switch Lever |
| 7 | Y27837 | | | Clip, Speed-"U" Type |
| 8 | 27248 | | Not Available | NUT,SPEED U-TYPE |
| 9 | 27250 | | Not Available | BRACKET,OUT-OF-BAL SWI |
| 10 | 27610 | | | Clip, U |
| 11 | Y00000000 | | Not Available | SEE NOTE CABINET TOP |
| 12 | 28291 | | Not Available | WASHER |
| 13 | 28193 | | | Screw, 8-1/2 Tapping W/ |