


# Amana HA7001 15 - OUTER TUB, COVER & PRESSURE HOSE



THROUGH  
L3627520

## OUTER TUB, COVER AND PRESSURE HOSE

Amana [Residential Amana HA7001 Washer Parts](#) Parts Diagram 15 - OUTER TUB, COVER & PRESSURE HOSE  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	25723	<a href="#">27001200</a>		Screw
2	<a href="#">03815</a>			Lockwasher, No.10 Ext Shk
3	<a href="#">27247</a>			Trigger, Out-Of-Bal Swi
4	27137	<a href="#">31153</a>		Cover Outer Tub
5	Y00000000		Not Available	SEE NOTE PRESSURE SWITCH
6	29077		Not Available	ASSY,PRESSURE FILL HOSxREPLACE
7	<a href="#">27184</a>			Gasket, Tub Cover
8	Y27017		Not Available	CLIP,SPRING
9	27071		Not Available	OUTER TUB
10	Y27195		Not Available	STICKER
11	Y00000000		Not Available	SEE NOTE SUPPORT LEG
12	<a href="#">27927</a>			Plate, Leg .032
13	<a href="#">27926</a>			Plate, Leg .063
14	27205	<a href="#">40128701</a>		Screw, 5/16-18 X .50
15	<a href="#">27239</a>			Spring, Leg