


# Amana HA7221 03 - AGITATOR & POST



## AGITATOR AND POST

Amana [Residential Amana HA7221 Washer Parts](#) Parts Diagram 03 - AGITATOR & POST

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	27707		Not Available	ASSY,DISPENSER-FABRIC
2	27138		Not Available	ASSY,AGITATOR CAP
3	<a href="#">27189</a>			Washer, Agitator Cap
4	27120		Not Available	ASSY,AGITATOR
5	27174		Not Available	DRIVE BLOCK
6	<a href="#">20243</a>			Pin, Taper
7	<a href="#">28091</a>			Assembly, Agitator Shaft anddr
8	20057	<a href="#">222T017P01</a>		Washer FIB 21/32 ID X 1156 OD X 1/8
9	<a href="#">04704</a>			Washer, .630idx1.125odx
10	28934		Not Available	AGITATOR POST ASSEMBLY
11	28933		Not Available	AGITATOR POST
12	27202	<a href="#">W10116787</a>		Screw
13	10429		Not Available	WASHER,THRUST
14	<a href="#">27164</a>			Washer, Spline
15	<a href="#">27197</a>			Ring, Retaining

"

28434P

Not Available

LOCTITE

