


Amana HE4330 04 - CONTROL PANEL & CONTROLS



CONTROL PANEL AND CONTROLS

Amana [Residential Amana HE4330 Dryer Parts](#) Parts Diagram 04 - CONTROL PANEL & CONTROLS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	27379		Not Available	ASSY,KNOB-SWITCH
2	91176			Lockwasher, 3/8 Intshkp
3	10519		Not Available	RETAINER
4	24205			Nut, Knurled 3/8-24
5	25124		Not Available	CONTROL HOOD END, LEFT
6	25126	5303284616		Clip
7	Y58032	58032		Switch
"	52623	58032		Switch
8	53516		Not Available	BUZZER
9	55985	W10116760		Screw
10	25820		Not Available	LOCKWASHER,1/2 INT SHK
11	52947			Nut, Hex 15/32-32
12	55882	55882P		Assembly- Switch
13	25232		Not Available	SCREW,8AB-18X7/8 OVAL
14	56260		Not Available	TIMER
15	25123		Not Available	CONTROL HOOD END, RIGHT

16	Y0056824	Not Available	SHIELD, ELECTRICAL
17	70212		Screw, 8-32 X 5/32 RD H
18	56508	Not Available	ASSY,KNOB-TIMER

