


# Amana HE7230 04 - CONTROL PANEL & CONTROLS



## CONTROL PANEL AND CONTROLS

Amana [Residential Amana HE7230 Dryer Parts](#) Parts Diagram 04 - CONTROL PANEL & CONTROLS  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	27379		Not Available	ASSY,KNOB-SWITCH
2	<a href="#">91176</a>			Lockwasher, 3/8 Intshkp
3	10519		Not Available	RETAINER
4	<a href="#">24205</a>			Nut, Knurled 3/8-24
5	25124		Not Available	CONTROL HOOD END, LEFT
6	25126	<a href="#">5303284616</a>		Clip
7	52623	<a href="#">58032</a>		Switch
8	53516		Not Available	BUZZER
9	55985	<a href="#">W10116760</a>		Screw
10	25820		Not Available	LOCKWASHER,1/2 INT SHK
11	<a href="#">52947</a>			Nut, Hex 15/32-32
12	55882	<a href="#">55882P</a>		Assembly- Switch
13	25232		Not Available	SCREW,8AB-18X7/8 OVAL
14	56260		Not Available	TIMER
15	25123		Not Available	CONTROL HOOD END, RIGHT
16	Y0056818		Not Available	SHELF, FREEZER

