


# Amana HS8031 06 - CONTROL PANEL (DRYER)



## CONTROL PANEL (DRYER)

Amana [Residential Amana HS8031 Washer Parts](#) Parts Diagram 06 - CONTROL PANEL (DRYER)

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	29910		Not Available	BUTTON,CONTROL-DARK BR
2	23962	<a href="#">W10116760</a>		Screw
3	<a href="#">30108</a>			Switch, 5 Position
4	30039		Not Available	COVER, SWITCH
5	<a href="#">28778</a>			Button, Control-Beige
6	29855		Not Available	GASKET,SHIELD
7	29808		Not Available	PLATE,SWITCH MOUNT
8	53516		Not Available	BUZZER
9	56260		Not Available	TIMER
10	30302	<a href="#">3030-2</a>		30 x 30 x 2 Cladlite AC Pad
11	29857		Not Available	CAP,END-R.H.
12	30292		Not Available	GASKET,END CAP & ADHES
13	29890		Not Available	COLLAR
14	29896		Not Available	PHILLIPS HEAD SCREW
15	Y00000000		Not Available	SEE NOTE WASHER OUTER CABINET

16	52864	<a href="#">500226</a>		Screw, 8b-16 x 5/8 Tap
17	30170		Not Available	ASSY,CONTROL PANEL-COM
18	<a href="#">70212</a>			Screw, 8-32 X 5/32 RD H
19	58772		Not Available	ASSY,KNOB-TIMER
20	28124		Not Available	ASSY,KNOB-SWITCH
21	10519		Not Available	RETAINER
22	29856		Not Available	GASKET,END CAP & ADHES
23	29858		Not Available	NO LONGER AVAILABLE
24	Y00000000		Not Available	SEE NOTE GROUND WIRE, GREEN

