


# Amana HZ1070 02 - CONTROL PANEL AND CONTROLS



Amana [Residential Amana HZ1070 Dryer Parts](#) Parts Diagram 02 - CONTROL PANEL AND CONTROLS  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
"	NOTE:		Not Available	NOTE: INDIVIDUAL WIRES NOT AVAILABLE SEPARATELY. ORDER COMPLETE WIRE HARNESS.
1	23406		Not Available	KNURLED NUT
2	M540054W		Not Available	CONTROL PANEL, WHITE
"	M540054A		Not Available	CONTROL PANEL, AVOCADO
"	M540054H		Not Available	CONTROL PANEL, HARVEST GOLD
3	25820		Not Available	LOCKWASHER, 1/2 INT SHK
4	<a href="#">52947</a>			Nut, Hex 15/32-32
5	53563		Not Available	SWITCH, DOOR RELEASE
6	M540055		Not Available	SPACER
7	<a href="#">03815</a>			Lockwasher, No.10 Ext Shk
8	M540185		Not Available	NUT
9	Y02728		Not Available	SCREW
10	M540191		Not Available	LOCKWASHER

11	M540242	Not Available	TIMER xREPLACE
12	Y00000000	Not Available	SEE NOTE CABINET ASSEMBLY
13	M540056	Not Available	PUSH NUT
14	10139	Not Available	CLIP
15	M540213	Not Available	KNOB, TIMER xREPLACE
16	M540258	Not Available	SWITCH xREPLACE
17	M540170	Not Available	DIAL, TIMER xREPLACE
18	Y20278	Not Available	LOCKWASHER
19	M540004	Not Available	SCREW
20	M540192	Not Available	DECAL

**Howes**  
*the laundry company*<sup>®</sup>

**Howes**  
*the laundry company*<sup>®</sup>

**Howes**  
*the laundry company*<sup>®</sup>