


# Amana LEA30AW (BOM: PLEA30AW) 03 - DOOR AND FRONT, ACCESS, AND TOP PANELS



Amana [Residential Amana LEA30AW \(BOM: PLEA30AW\) Dryer Parts](#) Parts Diagram 03 - DOOR AND FRONT, ACCESS, AND TOP PANELS  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">503688</a>			Screw, 10B-16 X .34 I
2	501086	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
3	500343		Not Available	PANEL,BACK(HOME HOOD)
4	24903R4		Not Available	STICKER
5	<a href="#">Y503876</a>			Clip, Hold Down
6	500085W	<a href="#">37001027</a>		Panel, Top
7	503661	<a href="#">27001200</a>		Screw
8	500084	<a href="#">40130801</a>		Bracket, Top Mount
9	32671	<a href="#">Y014874</a>		Screw, Idler Arm And Sleeve
10	<a href="#">505187</a>			Locator, Panel
11	56080	<a href="#">22001650</a>		Fastener, Spring
12	Y504570	<a href="#">W10169313</a>		Switch-Dor
13	504005	<a href="#">511056</a>		Seal Front Panel
14	503639W	<a href="#">503656WP</a>		Panel, Front

15	503661	<a href="#">27001200</a>	Screw
16	503648W	<a href="#">40045301WP</a>	Panel, Access
17	500281	Not Available	STICKER
18	54660	<a href="#">LA-1003</a>	Door Catch Kit
19	503643W	<a href="#">37001028</a>	Seal And Liner, Assembly
20	500039	<a href="#">510181</a>	Strike Doormetal
21	500223	<a href="#">40116201</a>	Bracket, Door Strike
23	503646W	<a href="#">R9800012</a>	Pull, Door
24	503642W	<a href="#">12002136</a>	Door Handle
25	<a href="#">Y503676</a>		Hinge, Door And Top
26	Y504105	<a href="#">Y504105A</a>	Rack-Dry
27	<a href="#">503126</a>		Plug, Hinge Hole

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>