



Amana Residential Amana LED250 (BOM: P7762211W) Washer Parts Diagram 06 - Page 1  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	R0603567		Not Available	HOOD, CONTROL
2	R0605689		Not Available	END CAP L
3	R0605690		Not Available	END CAP R
4	R0603577		Not Available	GRAPHICS PANEL
5	R0600095		Not Available	SCREW
6	R0604014		Not Available	TIMER 1 CYCLE
7	R0600097	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
10	R0610055		Not Available	TIMER, KNOB ASSEMBLY
15	R0605062		Not Available	CONTROL, SIGNAL
16	R0600004	<a href="#">W10116760</a>		Screw
17	R0601035		Not Available	NUT
18	R0610054		Not Available	ASSY,KNOB-ROTARY-BLK/O
19	R0601501		Not Available	CLIP
20	R0602530	<a href="#">58813P</a>		Switch W/Instructions
23	R0603114		Not Available	PANEL, REAR
24	R0600004	<a href="#">W10116760</a>		Screw

