


# Amana LES34AW (BOM: PLES34AW) 03 - Door and Front, Access, and Top Panels



Amana Residential Amana LES34AW (BOM: PLES34AW) Washer Parts Parts Diagram 03 - Door and Front, Access, and Top Panels  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">503688</a>			Screw, 10B-16 X .34 I
2	501086	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
3	500343		Not Available	PANEL,BACK(HOME HOOD)
4	24903		Not Available	STICKER,DISCONNECT POW
5	501241	<a href="#">Y503876</a>		Clip, Hold Down
6	500085WP	<a href="#">37001027</a>		Panel, Top
7	503661	<a href="#">27001200</a>		Screw
8	500084	<a href="#">40130801</a>		Bracket, Top Mount
9	32671	<a href="#">Y014874</a>		Screw, Idler Arm And Sleeve
10	56079	<a href="#">505187</a>		Locator, Panel
11	56080	<a href="#">22001650</a>		Fastener, Spring
12	Y504570	<a href="#">W10169313</a>		Switch-Dor
13	504005	<a href="#">511056</a>		Seal Front Panel

14	503656W	<a href="#">503656WP</a>	Panel, Front
15	503661	<a href="#">27001200</a>	Screw
16	503796W	<a href="#">40045301WP</a>	Panel, Access
17	500281	Not Available	STICKER
18	54660	<a href="#">LA-1003</a>	Door Catch Kit
19	503643W	<a href="#">37001028</a>	Seal And Liner, Assembly
20	500039	<a href="#">510181</a>	Strike Doormetal
21	500223	<a href="#">40116201</a>	Bracket, Door Strike
22	505050	<a href="#">500226</a>	Screw, 8b-16 x 5/8 Tap
23	503646W	<a href="#">R9800012</a>	Pull, Door
24	503654W	<a href="#">12002136</a>	Door Handle
25	<a href="#">Y503676</a>		Hinge, Door And Top
NI	503922	Not Available	ASSY, WIRING HARNESS

*the laundry company*<sup>®</sup>

**Howes**  
*the laundry company*<sup>®</sup>

**Howes**  
*the laundry company*<sup>®</sup>