



Amana Residential Amana LG1112 (BOM: P7762216W W) Washer Parts Parts Diagram 07 - Page 1  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	R0603593		Not Available	CONTROL, HOOD ASSY
2	R0605698		Not Available	END CAP, LEFT, BLACK
3	R0605696		Not Available	END CAP, RIGHT, BLACK
4	R0603592	<a href="#">61373</a>		Sub R0603592
5	R0600095		Not Available	SCREW
6	R0604014		Not Available	TIMER 1 CYCLE
7	R0600097	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
10	R0610064		Not Available	ASSY,TIMER KNOB & SKIRT
12	R0605703		Not Available	TRIM STRIP, LOWER
14	R0600093	<a href="#">31260</a>		Screw, No.8 X 3/8 Ind H
15	R0605062		Not Available	CONTROL, SIGNAL
17	R0601035		Not Available	NUT
18	R0601546	<a href="#">32866</a>		Assembly, Knob-Rotary-Black
19	R0601501		Not Available	CLIP
20	R0602530	<a href="#">58813P</a>		Switch W/Instructions
23	R0603167		Not Available	REAR PANEL

