



Amana Residential Amana LG1112 (BOM: P7762226W W) Dryer Parts Parts Diagram 06 - Page 1
 Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|----------------------|-----------------------|---------------|---|
| 1 | R0603593 | | Not Available | CONTROL, HOOD ASSY |
| 2 | R0605698 | | Not Available | END CAP, LEFT, BLACK |
| 3 | R0605696 | | Not Available | END CAP, RIGHT, BLACK |
| 4 | R0603592 | 61373 | | Sub R0603592 |
| 5 | R0600095 | | Not Available | SCREW |
| 6 | R0604014 | | Not Available | TIMER 1 CYCLE |
| 7 | R0600097 | 90767 | | Screw, 8A X 3/8 HeX Washer Head Tapping |
| 10 | R0610064 | | Not Available | ASSY,TIMER KNOB & SKIRT |
| 12 | R0605703 | | Not Available | TRIM STRIP, LOWER |
| 14 | R0600093 | 31260 | | Screw, No.8 X 3/8 Ind H |
| 15 | R0605062 | | Not Available | CONTROL, SIGNAL |
| 17 | R0601035 | | Not Available | NUT |
| 18 | R0601546 | 32866 | | Assembly, Knob-Rotary-Black |
| 19 | R0601501 | | Not Available | CLIP |
| 20 | R0601040 | | Not Available | TEMPERATURE SELECTOR SWITCH |

