



Amana Residential Amana LG2112L (BOM: P1122502W L) Dryer Parts Diagram 07 - Page 1
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	R0603627		Not Available	CONTROL HOOD ASSY
2	R0605698		Not Available	END CAP, LEFT, BLACK
3	R0605696		Not Available	END CAP, RIGHT, BLACK
4	R0603605		Not Available	GRAPHICS PANEL
5	R0600095		Not Available	SCREW
6	R0604014		Not Available	TIMER 1 CYCLE
7	R0600097	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
10	R0610064		Not Available	ASSY,TIMER KNOB & SKIRT
12	R0605703		Not Available	TRIM STRIP, LOWER
14	R0600093	31260		Screw, No.8 X 3/8 Ind H
15	R0605062		Not Available	CONTROL, SIGNAL
17	R0601035		Not Available	NUT
18	R0601546	32866		Assembly, Knob-Rotary-Black
19	R0601501		Not Available	CLIP
20	R0602540		Not Available	SWITCH,FABRIC SELECTOR
23	R0603167		Not Available	REAR PANEL

