



Amana Residential Amana LG2412 (BOM: P7762218W W) Washer Parts Parts Diagram 07 - Page 1
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	R0603593		Not Available	CONTROL, HOOD ASSY
2	R0605698		Not Available	END CAP, LEFT, BLACK
3	R0605696		Not Available	END CAP, RIGHT, BLACK
4	R0603591		Not Available	PANEL, GRAPHICS
5	R0600095		Not Available	SCREW
6	R0604013	502963		Timer, 3 Cycle
7	R0600097	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
10	R0610064		Not Available	ASSY,TIMER KNOB & SKIRT
12	R0605703		Not Available	TRIM STRIP, LOWER
14	R0600093	31260		Screw, No.8 X 3/8 Ind H
15	R0602003		Not Available	SWITCH, ROTARY ADJ.
17	R0601035		Not Available	NUT
18	R0601546	32866		Assembly, Knob-Rotary-Black
19	R0601501		Not Available	CLIP
20	R0602530	58813P		Switch W/Instructions
23	R0603167		Not Available	REAR PANEL

