



Amana Residential Amana LG2501 (BOM: P7762206W W) Dryer Parts Parts Diagram 07 - Page 1
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	R0603567		Not Available	HOOD, CONTROL
2	R0605677		Not Available	CAP END LH
3	R0605676		Not Available	CAP, END RH
4	R0603565		Not Available	PANEL GRAPHIC
5	R0600095		Not Available	SCREW
6	R0604015	502967P		Timer 5 Cycle Package
7	R0600097	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
8	R0602529		Not Available	SWITCH, TEMP
9	R0600094		Not Available	SCREW
10	R0610055		Not Available	TIMER, KNOB ASSEMBLY
11	R0605681		Not Available	TRIM STRIP, UPPER
12	R0605682		Not Available	TRIM BOTTOM
13	R0605063		Not Available	SLIDE, SIGNAL
14	R0600093	31260		Screw, No.8 X 3/8 Ind H
15	R0602002		Not Available	SIGNAL NON ADJ.
16	R0600004	W10116760		Screw

