


Amana LG2912 (BOM: P7804826W W) 01 - CABINET



Amana Residential Amana LG2912 (BOM: P7804826W W) Dryer Parts Parts Diagram 01 - CABINET
 Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|----------------------|-------------------------|---------------|-----------------------------|
| 1 | R0603041 | | Not Available | DUCT, EXHAUST |
| 2 | R0600052 | | Not Available | SCREW, HEX HEAD |
| 3 | R0603118 | | Not Available | CABINET W |
| " | R0603068 | | Not Available | xxxASSY, DRYER CABINET |
| 5 | R0603182 | 60821 | | Access Cover |
| 6 | R0600017 | | Not Available | SCREW |
| 7 | R0605711 | | Not Available | HINGE |
| 8 | R0603524 | 505187 | | Locator, Panel |
| 9 | R0600102 | Y014874 | | Screw, Idler Arm And Sleeve |
| 10 | R0606519 | Y56128 | | Pad, Bumper |
| 11 | R0603183 | 60811 | | Assembly, Base-Complete |
| 12 | R0600051 | Y305086 | | Adjustable Leg And Nut |
| 13 | R0601021 | 62739 | | Nut, Lock |
| 14 | R0606525 | Y314137 | | Foot, Rubber |
| 15 | R0603149 | | Not Available | TOP ASSY W |
| " | R0603148 | | Not Available | TOP, ASSY A |

