


# Amana LG4319L2 (BOM: PLG4319L2) 07 - GRAPHIC PANEL, CONTROL HOOD AND CONTROLS



Amana Residential Amana LG4319L2 (BOM: PLG4319L2) Dryer Parts Parts Diagram 07 - GRAPHIC PANEL, CONTROL HOOD AND CONTROLS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	500302		Not Available	COVER, TOP
2	501086	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
3	501881		Not Available	TIMER
4	34815		Not Available	PANEL, END R.H. (BLK)
5	500343		Not Available	PANEL, BACK(HOME HOOD)
6	500085P		Not Available	(ADD LETTER L-L, W-W TO PART N
8	500311	<a href="#">502220W</a>		Knob, Timer
9	<a href="#">34847</a>			Assembly, Knob-Rotary
10	24903		Not Available	STICKER, DISCONNECT POW
11	<a href="#">34816</a>			Panel, End
12	500300		Not Available	BRACKET, CONTROL SUPPORT-MECH
15	<a href="#">500823</a>			Signal, Rotary

