


# Amana LG4319W2 (BOM: PLG4319W2) 05 - GRAPHIC PANEL, CONTROL HOOD AND CONTROLS



Amana Residential Amana LG4319W2 (BOM: PLG4319W2) Dryer Parts Parts Diagram 05 - GRAPHIC PANEL, CONTROL HOOD AND CONTROLS  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	500305		Not Available	DIFFUSER W/OUT HOLE
2	501086	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
3	500302		Not Available	COVER, TOP
4	<a href="#">500823</a>			Signal, Rotary
5	<a href="#">502963</a>			Timer, 3 Cycle
6	34815		Not Available	PANEL, END R.H. (BLK)
7	500343		Not Available	PANEL, BACK(HOME HOOD)
8	500085P		Not Available	(ADD LETTER L-L, W-W TO PART N
9	502206		Not Available	GRAPHIC PANEL
"	502208		Not Available	PANEL, GRAPHICS
"	502630		Not Available	GRAPHIC PANEL
10	500311	<a href="#">50220W</a>		Knob, Timer
11	<a href="#">34847</a>			Assembly, Knob-Rotary

12	500300	Not Available	BRACKET,CONTROL SUPPORT-MECH
13	<a href="#">34816</a>		Panel, End
14	57584	Not Available	NUT
15	<a href="#">59704</a>		Bracket, Switch Mount
16	Y61511	Not Available	SWITCH,FABRIC SELECTOR

