


Amana LG8153WB (BOM: PLG8153WB) 07 - GRAPHIC PANEL, CONTROL HOOD AND CONTROLS



Amana Residential Amana LG8153WB (BOM: PLG8153WB) Dryer Parts Parts Diagram 07 - GRAPHIC PANEL, CONTROL HOOD AND CONTROLS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	500302		Not Available	COVER, TOP
2	501086	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
3	502967	502967P		Timer 5 Cycle Package
"	501881		Not Available	TIMER
4	34815		Not Available	PANEL, END R.H. (BLK)
5	500343		Not Available	PANEL, BACK(HOME HOOD)
6	500085P		Not Available	(ADD LETTER L-L, W-W TO PART N
7	502383		Not Available	PANEL, GRAPHICS
8	500311	502220W		Knob, Timer
9	34847			Assembly, Knob-Rotary
10	24903		Not Available	STICKER, DISCONNECT POW
11	34816			Panel, End
12	500300		Not Available	BRACKET, CONTROL

12	500300	Not Available	SUPPORT-MECH
14	62173		Switch, Temperature Select
15	500823		Signal, Rotary
17	500305	Not Available	DIFFUSER W/OUT HOLE

