


Amana LGA30AL (BOM: PLGA30AL) 02 - CONTROL PANEL



Amana [Residential Amana LGA30AL \(BOM: PLGA30AL\) Dryer Parts](#) Parts Diagram 02 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
2	503674L		Not Available	COVER, TOP
3	Y503997			Switch, Fabric Selector
4	504102	40070501		Buzzer, Adjustable
5	504179			Timer, 4 Cycle
6	504008L		Not Available	PANEL,END-RH ALMOND
7	Y00000000		Not Available	SEE NOTE SEE NOTE PANEL,HOME HOOD BACK
8	Y00000000		Not Available	SEE NOTE SEE NOTE Assy, Top Panel
9	503901		Not Available	PANEL,SUPPORT CONTROL (MECH)
10	503595L		Not Available	PANEL, GRAPHIC
11	502220L	40013601C		Assembly, Timer Knob
13	36701L			Knob
14	504009L		Not Available	PANEL,END LH ALMOND