


Amana LGA30AW (BOM: PLGA30AW) 02 - CONTROL PANEL



Amana Residential Amana LGA30AW (BOM: PLGA30AW) Dryer Parts Parts Diagram 02 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
2	503674W			Cover, Top
3	Y503997			Switch, Fabric Selector
4	504102	40070501		Buzzer, Adjustable
5	504179			Timer, 4 Cycle
6	504008W		Not Available	CAP-END RH
7	Y00000000		Not Available	SEE NOTE SEE NOTE PANEL,HOME HOOD BACK
8	Y00000000		Not Available	SEE NOTE SEE NOTE Assy, Top Panel
9	503901		Not Available	PANEL,SUPPORT CONTROL (MECH)
10	503595W		Not Available	PANEL, GRAPHIC
11	502220W			Knob, Timer
13	36701W			Knob
14	504009W	40012702W		Endcap